

FIG. 1A




FIG. 1B

FIG.2




FIG.3




FIG. 4

POWER ON/OFF REQUEST (SIMPLE BASE STATION TO PORTABLE TELEPHONE SET)

SIMPLE BASE STATION ID	PUBLIC BASE STATION ID	COMMAND RESPONSE CODE
------------------------	------------------------	-----------------------

401

01H: POWER ON/OFF REQUEST
F1H: STOP PS NUMBER NOTICE

STOP PS NUMBER NOTICE
(PORTABLE TELEPHONE SET TO SIMPLE BASE STATION)

402

SIMPLE BASE STATION ID	PUBLIC BASE STATION ID	COMMAND RESPONSE CODE	INFORMATION ELEMENT (PS ID)	LENG -TH (10)	PS TELEPHONE NUMBER	INFORMATION ELEMENT (SERVICE) (CLASS)	LENG -TH (1)	SERVICE CODE
------------------------	------------------------	-----------------------	-----------------------------	---------------	---------------------	---------------------------------------	--------------	--------------

403

404

405

SERVICE CODE

Bit 7

0

0 0 0 0 X X X X

VOICE MESSAGE

CHARACTER MESSAGE

AUTOMATIC ANSWERING SERVICE


TRANSFER SERVICE

COMMUNICATIONS SILENCE SETTING RELEASE

(PUBLIC BASE STATION TO POSITION MANAGEMENT SERVER)

SIMPLE BASE STATION ID	PS TELEPHONE NUMBER	COMMAND CODE	SERVICE CLASS	LENG -TH (1)	SERVICE CODE
------------------------	---------------------	--------------	---------------	--------------	--------------

02H: COMMUNICATIONS SILENCE SETTING
02H: COMMUNICATIONS SILENCE RELEASE

FIG.5
PRIOR ART

6/6
FIG.6
PRIOR ART

